


Modifier les paramètres Wi-Fi du modem-routeur ARRIS TG1652

- 1) Se connecter en local sur le modem via votre navigateur Internet à l'adresse <http://192.168.0.1/>
 - User Name : *admin*
 - Password : *password*
- 2) Paramètres Wi-Fi dans « System Basic Setup »



ARRIS | Wireless | HSD | Logout

Basic Setup | WAN Setup | LAN Setup | Wireless 2.4 GHz | Wireless 5 GHz | Firewall | USB | Utilities

BASIC SETUP

System Basic Setup

While your system has many configuration options, the options on this Basic Setup page are those required by most users. Click the tabs to access the other configuration pages to set advanced options. Hover the mouse pointer over the question mark icon next to an option to view a description of that option. For changes to take effect, you must click the Apply button.

Basic Setup

Language: English:English:English ?

Host Name: ARRISGW ?

Routing Enabled: ?

[More LAN Settings...](#)

Wireless 2.4 GHz

1 Enable Wireless ?

2 Wireless Network Name (SSID): ARRIS-6191 ?

3 Pre-Shared Key: BWR111100011 ?

[More Wireless Settings...](#)

Wireless 5 GHz

4 Enable Wireless ?

5 Wireless Network Name (SSID): ARRIS-6191-5G ?

6 Pre-Shared Key: BWR111100011 ?

[More Wireless Settings...](#)


2.4G/5G WPS Settings

WPS Enable: ?

Device PIN Code: 93161640 ?

WPS Mode: PBC ?

Enrollee PIN Code: ?

Start WPS Association:  ?

7 **Apply**

1. *Enable Wireless* : activer/désactiver le Wi-Fi 2.4 GHZ du modem.
2. *Wireless Network Name (SSID)* : nom du réseau Wi-Fi 2.4 GHZ.
3. *Pre-Shared Key* : Clé du réseau Wi-Fi 2.4 GHZ.
4. *Enable Wireless* : activer/désactiver le Wi-Fi 5 GHZ du modem.
5. *Wireless Network Name (SSID)* : nom du réseau Wi-Fi 5 GHZ.
6. *Pre-Shared Key* : Clé du réseau Wi-Fi 5 GHZ.
7. Pour appliquer les modifications, cliquer sur *Apply* en bas de la page.

Vialis – 10 rue des Bonnes Gens – CS 70187 – 68004 Colmar Cedex
Assistance technique : 09 73 01 02 03* – E-mail : info@vialis.net – Site internet : telecoms.vialis.net

